

**Hasselblad**  
**September, 2015**

## **GIL (GPS accessory) Firmware: GIL150220.hbf**

This package contains firmware version 4.0.0 for the GIL GPS accessory.

### **Changes in 4.0.0:**

- The new firmware addresses a stability issue and is recommended for customers that have experienced "Reattach accessory"

## **Installation**

Manual updating of firmware is available in the Phocus software, from version 2.7 Mac and 2.7 Windows. However, please use the latest version of Phocus for firmware updating. For Windows it is strongly recommended to use the 64 bit version.

The update should preferably be made by an authorized Hasselblad service centre but can also be made using the following procedure.

Procedures for updating camera body firmware via the Phocus software:

In order to perform the update, the GIL unit must be attached to the camera.

1. Unzip the downloaded file.
2. Make sure your camera is turned on.
3. Connect the camera to Phocus using a POWERED FireWire cable.
4. Go to "File" and then "Update Firmware" and locate the desired firmware package (GIL150220.hbf) on your computer, and click "Update".
5. Follow the instructions provided from the software carefully! Do not switch off the camera during the update process, unless specifically requested by the Phocus software.
6. When the update has been finalized, please restart your camera and check that the firmware has been successfully updated.

**IMPORTANT NOTICE: During the upgrade procedure do NOT disconnect the FireWire cable until prompted!**

Unintentionally removing the FireWire cable during the firmware download procedure could in worst case render the camera useless which would require the need for authorized service.