

Firmware 1.17.2 for Hasselblad X1D-50c

The 1.17.2 release is a feature release for the X1D-50c camera that adds new functionality:
See User Guide version 1.6 for more detailed information.

New features:

- Re-sizeable AF points:
 - 4 mm (35 points)
 - 2.8 mm (63 points)
 - 2 mm (117 points)
- Electronic Shutter
 - Noise-less exposures. Providing shutter speeds between 68 minutes and 1/10000 second.


Update procedure

Make sure that you use a fully charged battery on the camera. A charge level of 50% or more is required. Please note that the update procedure normally takes about 7-10 minutes, but can in some cases take up to 12 minutes.


Note: It is not allowed to have the USB cable inserted during the update process.

Note: Once the update is completed you must remove and reinsert the battery.


Copy the downloaded file (X1D_v1_17_2.cim) to the SD card and insert it into the camera. Then follow the procedure below:



1: Select the "Settings Menu" from the main menu.



2: Select "Service"



3: Click "Check for update" and select the file "X1D_v1_17_2.cim" from the list. Finally click "Upgrade".

August 20, 2017 / The Hasselblad Team