

Firmware 1.14.2 for Hasselblad X1D-50c Demo cameras


The 1.14.2 release is a feature update for the X1D Demo Cameras that adds many new functions and improved stability.

Update procedure


Make sure that you use a fully charged battery on the camera. A charge level of 85% or more is required. Please note that the update procedure normally takes about 7-10 minutes, but can in some cases take up to 12 minutes.

Note: Once the update is completed you must remove and reinsert the battery.


Copy the downloaded file (X1D_v1_14_2.cim) to the SD card. Then follow the procedure below:



1: Select the "Settings Menu" from the main menu.



2: Select "Service"



3: Click "Check for update" and select the file "X1D_v1_14_2.cim" from the list. Finally click "Upgrade".

Added functionality and main improvements for X1D

Compared to v1.12.0:

- Selectable AF point
- Auto White Balance
- Exposure simulation on LCD/EVF
- B and T-modes
- Lens firmware can be updated through the camera
- Improved stability when the battery is low
- Language updates
- Bug fixes

December 12, 2016

The Hasselblad Team