

## Hasselblad September, 2015

### Firmware version 3.3.3/1.1.5 for H5D camera body

This package contains firmware version 3.3.3/1.1.5 for the H5D camera body.

Changes since version 3.3.2/1.1.4

- Solves a rare issue where a short extra delay could be added to the exposure sequence
- Internal production support

### Installation

The update should preferably be made by an authorized Hasselblad service centre but can also be made using the following procedure:

- In order to perform the update the H5D sensor unit must be attached to the camera body.
- Remove lens and viewfinder and connect the camera to the host computer using a FireWire cable. Make sure the computer has a fresh battery or is powered from the mains supply.
- Start Phocus and when the camera is connected, as indicated by an active camera icon in the top left part of the screen, select "Update Firmware..." from the "File" menu. Browse to the location where the update file (H5D150601.hbf) was saved and follow the instructions on screen.
- The update procedure will take a few minutes to finish.

### Limitations

Please use the latest version of Phocus for firmware updating. For Windows it is strongly recommended to use the 64 bit version.

Use a computer with a powered FireWire cable for the update.